

2025 Land Cruiser

5 Things You Need to Know

- * Standard i-FORCE MAX Hybrid EV system
- * Standard Full-Time 4WD
- * Heritage-inspired exterior styling
- * Toyota Audio Multimedia with available 12.3-in. touchscreen
- * Toyota Safety Sense™ 3.0[1]

What's New

Toyota Land Cruiser returns to its off-road roots backed by a heritage-inspired look. Powered exclusively by the i-FORCE MAX Hybrid EV system, this legendary SUV couples impressive capability off the pavement with a refined on-road drive.

Awards

- Awards coming soon.

Models

Model Code	Trim Name	Full Name	Engine
6165	Land Cruiser 1958	Land Cruiser 1958	2.4L 4-cyl.
6167	Land Cruiser	Land Cruiser	2.4L 4-cyl.

Key Features

Land Cruiser 1958

Land Cruiser pays homage to its rugged roots. Enhanced performance thanks to a standard electrified powertrain, plus a generous list of standard equipment makes this

icon a strong value among off-road-oriented[2] SUVs.

- 326-hp i-FORCE MAX Hybrid EV powertrain
- Full-Time 4WD
- Round LED headlights
- 18-in. alloy wheels
- Toyota Safety Sense™ 3.0[1]

Land Cruiser

Premium appointments meet rugged capability thanks to Land Cruiser's upscale cabin. Features like available heated and ventilated front seats, an available head-up display, and an available 12.3-inch touchscreen bring convenience, as well as a high-tech feel to this capable SUV.

- Rectangular LED headlights
- Available 20-in. alloy wheels
- Power liftgate
- 2400-kW AC Inverter[3]
- Toyota Audio Multimedia with available 12.3-in. touchscreen

Colors

Availability - X

Exterior Color (paint code)	Interior Color (paint code)	Land Cruiser 1958	Land Cruiser
Ice Cap (040)	Black Fabric (20-FB)	X	
Black (202)	Black Fabric (20-FB)	X	
Meteor Shower (04V8)	Black Fabric (20-FB)	X	
Ice Cap (040)	Java SofTex® Trim (40-EB)		X
Ice Cap (040)	Black Leather Trim (20-LB)		X
Ice Cap (040)	Black SofTex® Trim (20-EB)		X
Ice Cap (040)	Java Leather Trim (40-LB)		X
Wind Chill Pearl (089)	Java SofTex® Trim (40-EB)		X
Wind Chill Pearl (089)	Black Leather Trim (20-LB)		X
Wind Chill Pearl (089)	Black SofTex® Trim (20-EB)		X
Wind Chill Pearl (089)	Java Leather Trim (40-LB)		X
Underground (1L7)	Java SofTex® Trim (40-EB)		X
Underground (1L7)	Black Leather Trim (20-LB)		X
Underground (1L7)	Black SofTex® Trim (20-EB)		X
Underground (1L7)	Java Leather Trim (40-LB)		X

Exterior Color (paint code)	Interior Color (paint code)	Land Cruiser 1958	Land Cruiser
Black (202)	Java SofTex® Trim (40-EB)		X
Black (202)	Black Leather Trim (20-LB)		X
Black (202)	Black SofTex® Trim (20-EB)		X
Black (202)	Java Leather Trim (40-LB)		X
Trail Dust w/ Grayscape Roof Two-Tone Exterior Color (2ZC)	Java SofTex® Trim (40-EB)		X
Trail Dust w/ Grayscape Roof Two-Tone Exterior Color (2ZC)	Black Leather Trim (20-LB)		X
Trail Dust w/ Grayscape Roof Two-Tone Exterior Color (2ZC)	Black SofTex® Trim (20-EB)		X
Trail Dust w/ Grayscape Roof Two-Tone Exterior Color (2ZC)	Java Leather Trim (40-LB)		X
Heritage Blue w/ Grayscape Roof Two-Tone Exterior Color (2ZD)	Java SofTex® Trim (40-EB)		X
Heritage Blue w/ Grayscape Roof Two-Tone Exterior Color (2ZD)	Black Leather Trim (20-LB)		X
Heritage Blue w/ Grayscape Roof Two-Tone Exterior Color (2ZD)	Black SofTex® Trim (20-EB)		X
Heritage Blue w/ Grayscape Roof Two-Tone Exterior Color (2ZD)	Java Leather Trim (40-LB)		X
Meteor Shower (04V8)	Java SofTex® Trim (40-EB)		X
Meteor Shower (04V8)	Black Leather Trim (20-LB)		X
Meteor Shower (04V8)	Black SofTex® Trim (20-EB)		X
Meteor Shower (04V8)	Java Leather Trim (40-LB)		X
Heritage Blue (08X0)	Java SofTex® Trim (40-EB)		X
Heritage Blue (08X0)	Black Leather Trim (20-LB)		X
Heritage Blue (08X0)	Black SofTex® Trim (20-EB)		X
Heritage Blue (08X0)	Java Leather Trim (40-LB)		X

Factory Options

Land Cruiser 1958

Rear Bumper Guard - \$230

- Code: BG
- Rear Bumper Guard

Liftgate Light - \$195

- Code: TL
- Liftgate Light

Land Cruiser

Moonroof - \$850

- Code: MR
- Power tilt/slide moonroof with sunshade

20-in. Wheels - \$1,240

- Code: AA
- 20-in. Gray Alloy Wheels

Rear Bumper Guard - \$230

- Code: BG
- Rear Bumper Guard

Liftgate Light - \$195

- Code: TL
- Liftgate Light

Two-Tone Roof - \$350

- Code: TX
- Two-Tone Body Color[4]

Stabilizer Disconnect Mechanism - \$1,230

- Code: SF
- Stabilizer Disconnect Mechanism (SDM)

Packages

Land Cruiser 1958

No packages available at this time

Land Cruiser

Land Cruiser Premium Package - \$4,600

- Code: PP
- 14-speaker JBL®[5] Premium Audio System including subwoofer and amplifier, illuminated entry with illuminated running boards, power moonroof, rear console cool box, digital rearview mirror, Qi-compatible wireless charging[6], memory/power driver's seat, power front passenger's seat, Head Up Display (HUD), Lane Change Assist (LCA)[7], Front Cross-Traffic Alert (FCTA)[8] and Traffic Jam Assist[9] (requires an active

Drive Connect trial or subscription; 1-year trial included on all grades but 1958[10]) 4G network dependent

Features

S - Standard | O - Optional | P - Package

	Land Cruiser 1958	Land Cruiser
Safety/Convenience		
Airbags		
9 airbags[29] – Advanced Airbag System with driver and front passenger dual stage airbags, driver and front passenger seat-mounted side airbags, driver and front passenger knee airbags, front passenger seat cushion airbag, and front and rear side curtain airbags	S	S
Backup Camera		
Multi-Terrain Monitor with selectable front, side or rear views	–	S
Integrated backup camera display with projected path[31]	S	S
Braking Systems		
Brake Assist (BA) – part of Star Safety System™	S	S
Electronic Brake-force Distribution (EBD) – part of Star Safety System™	S	S
Electronic parking brake (EPB)[32]	S	S
Hill Start Assist Control (HAC)[23]	S	S
Anti-lock Brake System (ABS) – part of Star Safety System™	S	S
Pre-Collision System with Pedestrian Detection (PCS w/ PD)[33] – part of Toyota Safety Sense™ 3.0[1]	S	S
Smart Stop Technology® (SST)[34] – part of Star Safety System™	S	S
Convenience		
Power door locks with shift-linked automatic lock/unlock feature	S	S
Power windows with one-touch auto up/down with jam protection in all positions	S	S
Smart Key System on front driver and passenger side doors and liftgate with Push Button Start, remote keyless entry system, and remote illuminated entry	S	S
Digital Key – requires an active Remote Connect trial or subscription (standard with Premium Package). 4G network dependent.[17]	–	P
Cruise Control		
Dynamic Radar Cruise Control (DRCC)[35] – part of Toyota Safety Sense™ 3.0[1]	S	S
Safety & Security		
Safety Connect® with up to a 10-year trial subscription. 4G network dependent[18] – part of Connected Services[16]	S	S
Automatic Collision Notification – part of Safety Connect® 3-year trial subscription. 4G network dependent [18]	S	S
Emergency Assistance – part of Safety Connect® with up to a 10-year trial subscription. 4G network dependent[18]	S	S
Enhanced Roadside Assistance[36] – part of Safety Connect® with up to a 10-year trial subscription. 4G network dependent[18]	S	S

	Land Cruiser 1958	Land Cruiser
Stolen Vehicle Locator[37] – part of Safety Connect® with up to a 10-year trial subscription. 4G network dependent[18]	S	S
Star Safety System™	S	S
Brake Assist (BA) – part of Star Safety System™	S	S
Electronic Brake-force Distribution (EBD) – part of Star Safety System™	S	S
Anti-lock Brake System (ABS) – part of Star Safety System™	S	S
Smart Stop Technology® (SST)[34] – part of Star Safety System™	S	S
Enhanced Vehicle Stability Control (VSC)[38] – part of Star Safety System™	S	S
Toyota Safety Sense™ 3.0[1]	S	S
Pre-Collision System with Pedestrian Detection (PCS w/ PD)[33] – part of Toyota Safety Sense™ 3.0[1]	S	S
Full-Speed Range Dynamic Radar Cruise Control (DRCC)[35] – part of Toyota Safety Sense™ 3.0[1]	S	S
Lane Departure Alert with Steering Assist (LDA w/ SA)[39] – part of Toyota Safety Sense™ 3.0[1]	S	S
Automatic High Beams (AHB)[40] – part of Toyota Safety Sense™ 3.0[1]	S	S
Lane Tracing Assist (LTA)[41] – part of Toyota Safety Sense™ 3.0[1]	S	S
Road Sign Assist (RSA)[42] – part of Toyota Safety Sense™ 3.0[1]	S	S
Proactive Driving Assist (PDA)[43] – part of Toyota Safety Sense™ 3.0[1]	S	S
Blind Spot Monitor (BSM)[44] with Rear Cross-Traffic Alert (RCTA)[45] and Trailer Merge Warning[46]	S	S
Front Cross Traffic Alert (FCTA)[8]	–	P
Traffic Jam Assist (TJA)[9]	–	P
Lane Change Assist (LCA)[7]	–	P
Safe Exit Alert (SEA)[47]	S	S
Front and Rear Parking Assist with Automatic Braking (PA w/ AB)[48]	S	S
Tire Pressure Monitor System (TPMS)[49] with direct pressure read-out and individual tire location alert	S	S
Trailer-Sway Control (TSC)[50]	S	S
Anti-theft system with engine immobilizer[51]	S	S
Child-protector rear door locks and power window lockout control	S	S
Driver and front passenger active headrests	S	S
Seatbelts & Child Restraint System		
3-point seatbelts for all seating positions; driver-side Emergency Locking Retractor (ELR); Automatic/Emergency Locking Retractor (ALR/ELR) on all passenger belts	S	S
Adjustable front- and second-row outboard seatbelt anchors	S	S
Driver and front passenger Active Seatbelt Pretensioning System with force limiters	S	S
LATCH (Lower Anchors and Tethers for CHildren) includes lower anchors on outboard second-row seats and tether anchors on all second-row seats	S	S
Windows, Glass & Wipers		
Rain-sensing aerodynamic variable intermittent windshield wipers	S	S
Intermittent rear wiper	S	S
Windshield wiper de-icer	S	S
Privacy glass on rear side, quarter and liftgate windows	S	S
Interior		
Air Conditioner, Heater & Defroster		
Three-zone automatic front and rear climate control, push-button controls, separate second-row control panel, individual temperature settings for driver, front passenger and rear-seat passengers	S	S

	Land Cruiser 1958	Land Cruiser
Audio, Entertainment & Navigation		
Toyota Audio Multimedia with 8-in. touchscreen	S	–
Toyota Audio Multimedia with available 12.3-in. touchscreen	–	S
Wireless Apple CarPlay® compatibility[13]	S	S
Wireless Android Auto™ ccompatibility[14]	S	S
3-month SiriusXM® trial[15]	S	S
6-speaker audio system	S	–
10-speaker audio system	–	S
14-speaker JBL®[5] Premium Audio system including subwoofer and amplifier	–	P
Drive Connect with 1-year trial[10](1-year trial included on all grades but 1958) – part of Connected Services 4G network dependent[16]	–	S
Remote Connect with 1-year trial. 4G network dependent[17]. – part of Connected Services[16]	S	S
Safety Connect® with up to a 10-year trial. 4G network dependent[18]. – part of Connected Services[16]	S	S
Service Connect with up to a 10-year trial. 4G network dependent[19]. – part of Connected Services[16]	S	S
Wi-Fi Connect with up a 3GB/1-month trial. Subscription required after trial. 4G network dependent[20]. – part of Connected Services[16]	S	S
Cargo Area		
All-weather floor liners[21]	–	S
Cup & Bottle Holders		
12 cup and bottle holders	S	S
Drive Modes		
Drive Mode Select (DMS) with Sport, Eco, Normal and Snow Modes	S	S
Crawl Control (CRAWL)[22] with Downhill Assist Control (DAC)[23]	S	S
Multi-Terrain Select (MTS) with Auto, Dirt, Sand, Mud, Rock, and Deep Snow	–	S
Stabilizer Disconnect Mechanism (SDM)	–	O
Instrumentation		
Digital gauge cluster with 7-in. color Multi-Information Display (MID)	S	–
12.3-in. digital gauge cluster with selectable gauge display screens and fuel economy, Driver Assist, vehicle/trip information, and warning messages	–	S
Head-up display (HUD)	–	P
Lights		
Illuminated vanity mirrors in driver and front passenger sun visors	S	S
Overhead console with LED illumination, LED maplights, and Safety Connect®[18] controls	S	S
Second-row LED maplights	S	S
Second-row and cargo-area LED illumination	S	S
Illuminated entry	–	S
Mirrors		
Auto-dimming rearview mirror with compass and HomeLink®[24] universal transceiver	S	S
Digital display auto-dimming rearview mirror with compass and HomeLink®[24] universal transceiver	–	P
Power Outlets		
One center console-area 12V auxiliary power outlet[25] and one rear cargo area 120V AC power outlet[26]	S	S
2400W AC inverter[3]	S	S
6 USB ports[27]	S	S

	Land Cruiser 1958	Land Cruiser
Qi-compatible wireless charging[6]	–	P
Seats		
5-passenger seating	S	S
Fabric-trimmed seats	S	–
Manual Driver Cushion Length Adjuster	–	P
Driver's seat memory function	–	P
6-way manually-adjustable driver's seat	S	–
8-way power-adjustable driver's seat	–	S
6-way manually-adjustable front passenger's seat	S	S
8-way power-adjustable passenger seat	–	P
Heated front seats	S	–
Heated and ventilated front seats	–	S
Driver's seat lumbar adjustment	–	P
SofTex®-trimmed[28] seats	–	S
Leather-trimmed seats	–	P
Front passenger seatback pockets	S	–
Steering Wheel		
Power tilt/telescopic steering wheel with TOYOTA badge	–	S
Manual tilt/telescopic steering wheel with TOYOTA badge	S	–
Heated steering wheel	S	S
Storage Areas		
Console cool box	–	P
Trim		
Leather-trimmed shift lever	S	S
Exterior		
Lights		
Heritage-inspired circular LED headlights	S	–
Rectangular LED headlights	–	S
Integrated LED Daytime Running Lights (DRL)	S	S
Front LED integrated fog lights	S	–
Rigid Industries®[11] LED Color-Selecting Fog Lights	–	S
Mirrors		
Outside mirrors with turn signal indicators, vortex generators, and auto-dimming, and automatic power-folding	S	–
Outside mirrors with turn signal indicators, vortex generators, and auto-dimming, automatic power-folding, and reverse tilt-down features	–	S
Heated outside mirrors	–	S
Moonroof		
Power tilt/slide moonroof with sunshade	–	O
Racks		
Roof rails[12]	–	S
Skid Plates		

	Land Cruiser 1958	Land Cruiser
Front skid plate with engine, transmission, and transfer case protection	S	S
Trim		
Black-painted "TOYOTA" heritage grille	S	S
Running boards	–	S
Illuminated running boards	–	P
Front and rear frame-mounted tow hooks	S	S
Front and rear heavy-duty mudguards	–	–
Adjustable power liftgate with jam protection[59]	–	S
Rear Land Cruiser badge	S	S
Black door handles	S	S
Gloss-black hood finisher	–	S
Standard mudguards	S	S
Wheels & Tires		
18-in. dark gray metallic-finished alloy wheels	S	–
18-in. matte-gray-painted alloy wheels	–	S
20-in. gray-painted alloy wheels	–	O
Windows, Glass & Wipers		
Rain-sensing aerodynamic variable intermittent windshield wipers	S	S
Intermittent rear wiper	S	S
Windshield wiper de-icer	S	S
Privacy glass on rear side, quarter and liftgate windows	S	S

Specs

	Land Cruiser 1958	Land Cruiser
Body Construction		
Type	Unitized steel body on 10-member high-tensile steel ladder frame	Unitized steel body on 10-member high-tensile steel ladder frame
Brakes		
Front disc brake rotor diameter (in.)	13.1 x 1.2-in. power-assisted front with hydraulic brake booster and Star Safety System™	13.1 x 1.2-in. power-assisted front with hydraulic brake booster and Star Safety System™
Rear disc brake rotor diameter (in.)	13.1 x 0.78-in. power-assisted rear with hydraulic brake booster and Star Safety System™	13.1 x 0.78-in. power-assisted rear with hydraulic brake booster and Star Safety System™
Dimensions – Exterior		
Overall length (in.)	196.4	196.4
Width (in.)	77.9	77.9
Overall width (in.) (with mirrors)	83.2	83.2
Overall height (in.)	75.7	76.1
Track width – front (in.)	64.7	65.5
Track width – rear (in.)	65.6	65.6
Approach/departure angles (degrees)	30/22	30/22
Running ground clearance (in.)	8.3	8.3
Ground clearance (in.)	7.9	7.9
Fording depth (in.)	–	–
Wheelbase (in.)	112.2	112.2

	Land Cruiser 1958	Land Cruiser
Dimensions – Interior		
Head room – first/second row (in.)	40.1/39.3	40.1/39.3
Head room – first/second row (in.) with moonroof	–	39.3/38.5
Shoulder room – first/second row (in.)	58.5/29.2	58.5/29.2
Hip room – first/second row (in.)	55.4/57	55.4/57
Leg room – first/second row (in.)	43/36.7	43/36.7
Drive Battery		
Type	Sealed Nickel Metal Hydride (Ni-MH) with 1.87 kWh capacity	Sealed Nickel Metal Hydride (Ni-MH) with 1.87 kWh capacity
Voltage (V)	288	288
Drive Systems & Differentials		
Drivetrain layout	Full-Time 4-Wheel Drive with Active Traction Control (A-TRAC) and Torsen ^{®A} limited-slip center differential with locking feature	Full-Time 4-Wheel Drive with Active Traction Control (A-TRAC) and Torsen ^{®A} limited-slip center differential with locking feature
Differentials	Electronically controlled locking rear and center differentials	Electronically controlled locking rear and center differentials
Differential ratio – rear axle	–	–
Differential ring gear – front/rear (in.)	–	–
Transfer case ratio – high/low	–	–
Engines		
Type	2.4L i-FORCE MAX turbocharged inline 4-cyl. hybrid powertrain	2.4L i-FORCE MAX turbocharged inline 4-cyl. hybrid powertrain
Net combined horsepower (hp)	326 6000 rpm	326 6000 rpm
Torque (lb.-ft.)	465 1700 rpm	465 1700 rpm
Injection system	D-4ST direct injection and port injection	D-4ST direct injection and port injection
Oil classification	–	–
Oil type / weight	–	–
Fuel Facts		
EPA-estimated mpg rating (city/hwy/combined)[52]	22/25/23	22/25/23
EPA-est. MPGe	–	–
Fuel tank capacity (gal.)	17.9	17.9
Recommended fuel	91 octane or higher	91 octane or higher
Federal emissions rating	Ultra Low Emission Vehicle BIN 50	Ultra Low Emission Vehicle BIN 50
California emissions rating	–	–
Safety		
Total number of airbags[29]	9	9
Front airbags[29]	Driver and front passenger Advanced Airbag System; front passenger seat cushion airbag	Driver and front passenger Advanced Airbag System; front passenger seat cushion airbag
Knee airbags[29]	Driver and front passenger	Driver and front passenger
Seat-mounted side airbags[29]	Driver and front passenger; second-row outboard	Driver and front passenger; second-row outboard
Side curtain airbags[29]	Front and rear side curtain airbags	Front and rear side curtain airbags
Driver seatbelt	3-point seatbelt; Emergency Locking Retractor (ELR); adjustable seatbelt anchor	3-point seatbelt; Emergency Locking Retractor (ELR); adjustable seatbelt anchor
Front passenger seatbelt	3-point seatbelt; Automatic/Emergency Locking Retractor (ALR/ELR); adjustable seatbelt anchor	3-point seatbelt; Automatic/Emergency Locking Retractor (ALR/ELR); adjustable seatbelt anchor
Rear passenger seatbelts	3-point seatbelts; Automatic/Emergency Locking Retractor (ALR/ELR); adjustable second-row outboard seatbelt anchors	3-point seatbelts; Automatic/Emergency Locking Retractor (ALR/ELR); adjustable second-row outboard seatbelt anchors
LATCH locations	Lower anchors on outboard second-row seats; tether anchors on all second-row seats	Lower anchors on outboard second-row seats; tether anchors on all second-row seats
Steering		
Type	Vehicle speed-sensing, variable gear ratio, power-assisted rack-and-pinion	Vehicle speed-sensing, variable gear ratio, power-assisted rack-and-pinion
Turning radius – curb-to-curb (ft.)	20	20
Suspension		
Front	Independent double-wishbone with coil springs and stabilizer bar	Independent double-wishbone with coil springs and stabilizer bar
Rear	4-link with coil springs, stabilizer bar and semi-floating axle	4-link with coil springs, stabilizer bar and semi-floating axle
Stabilizer Disconnect Mechanism (SDM)	–	O
Towing		
Maximum towing weight (lb.)[53]	6,000	6,000
Towing hitch	Integrated towing receiver hitch and wiring harness with 4/7-pin connectors	Integrated towing receiver hitch and wiring harness with 4/7-pin connectors
Transmissions		
Type	8-speed Electronically Controlled Automatic Transmission with intelligence (ECT-i); sequential shift mode and uphill/downhill logic	8-speed Electronically Controlled Automatic Transmission with intelligence (ECT-i); sequential shift mode and uphill/downhill logic
Gear ratios	1st: 4.41 2nd: 2.80	1st: 4.41 2nd: 2.80

	Land Cruiser 1958	Land Cruiser
	3rd: 1.95 4th: 1.51 5th: 1.27 6th: 1.00 7th: 0.79 8th: 0.65 Reverse: 3.64	3rd: 1.95 4th: 1.51 5th: 1.27 6th: 1.00 7th: 0.79 8th: 0.65 Reverse: 3.64
Warranties & Maintenance		
Basic warranty	3 years / 36,000 miles	3 years / 36,000 miles
Powertrain warranty	5 years / 60,000 miles	5 years / 60,000 miles
Corrosion Perforation warranty	5 years / Unlimited miles	5 years / Unlimited miles
Emissions warranty	Refer to Vehicle Warranty & Maintenance Guide	Refer to Vehicle Warranty & Maintenance Guide
Hybrid System warranty[54]	8 years / 100,000 miles	8 years / 100,000 miles
Hybrid Battery warranty[55]	10 years /150,000 miles	10 years /150,000 miles
Accessories warranty	3 years / 36,000 miles	3 years / 36,000 miles
Restraint systems warranty	5 years / 60,000 miles	5 years / 60,000 miles
ToyotaCare maintenance plan[56]	2 years / 25,000 miles	2 years / 25,000 miles
ToyotaCare roadside assistance coverage[56]	2 years / Unlimited miles	2 years / Unlimited miles
Weights & Capacities		
Cargo volume (behind 2nd row) (cu. ft.)[57]	46.2	46.2
Cargo volume (behind 1st row) (cu. ft.)[57]	82.1	82.1
Curb weight (minimum) (lb.)	5360	5445
GVWR (lb.)	6725	6725
GCWR (lb.)	12725	12945
Payload (lb.)[58]	–	–
Fuel tank (gal.)	17.9	17.9
Seating capacity	5	5
Wheels & Tires		
Wheel type	Alloy	Alloy
Wheel size (in.)	18	18; Available 20
Tire size	P245/70R18 116V	P265/70R18; P265/50R20
Tire type	–	–
Spare	Full-size spare on alloy wheel, mounted under body	Full-size spare on alloy wheel, mounted under body

Disclaimers

1. Toyota Safety Sense effectiveness depends on many factors including road, weather and vehicle conditions. Drivers are responsible for their own safe driving. Always pay attention to your surroundings and drive safely. See *Owner's Manual* for limitations.
2. The Toyota Land Cruiser is designed to meet most off-road driving requirements, but off-roading is inherently dangerous and may result in personal injury or vehicle damage. Toyota encourages responsible operation to help protect you, your vehicle and the environment.
3. Rated for 2400 watts for a single three-prong outlet for short term use. See *Owner's Manual* for additional limitations and details.
4. Extra-cost color.
5. JBL is a registered trademark of Harman International Industries, Inc.
6. Wireless charging may not be compatible with all mobile phones, smart devices, tablets, e-readers, MP3/WMA players and like models.
7. Lane Change Assist operates only when Dynamic Radar Cruise Control (DRCC) and Lane Tracing Assist (LTA) are activated. Do not overly rely on this system. Driver must confirm lane is clear. See *Owner's Manual* for limitations.
8. Do not overly rely on the Front Cross-Traffic Alert system. Always visually confirm that it is safe to proceed. See *Owner's Manual* for limitations.
9. Traffic Jam Assist is not an automated driving system, requires driver supervision at all times, and is designed to function on controlled access freeways at speeds of 25 mph or less. Use this system in accordance with applicable laws. Requires an active subscription to Drive Connect, which depends on 4G network availability and other factors outside Toyota's control. Also requires account registration through Toyota App and acceptance of Connected Services Terms of Use at Connected Services Terms of Use and Master Data Consent. Before operating, refer to *Owner's Manual* for instructions and limitations.
10. Drive Connect availability and accuracy depend on certain factors outside of Toyota's control in order to operate, including 4G network availability, a cellular connection and GPS signal. Without any one or more of these things, operability may be limited or

precluded. Services may vary and are subject to change without notice. Services require account registration through Toyota App and acceptance of Connected Services Terms of Use at www.toyota.com/content/dam/toyota/privacyvts/pdf/connected-services-terms-use.pdf and Master Data Consent. Data charges may apply. For Toyota Connected Services' vehicle-generated data collection, use, sharing, and retention practices and agreements, see www.toyota.com/support/privacy-notice/. Trial period begins on original purchase or lease date of new vehicle. Services may vary and are subject to change without notice. Requires app download/registration, acceptance of Terms of Use and subscription after trial (if applicable). Data charges may apply.

11. Rigid Industries is a registered trademark of JST Performance, LLC d/b/a Rigid Industries.
12. Do not overload your vehicle. See *Owner's Manual* for weight limits and restrictions.
13. Apple CarPlay requires a compatible iPhone with an active data plan. Check compatibility at www.apple.com/ios/carplay/. Operability depends on network availability, a cellular connection and GPS signal. Services vary by vehicle and are subject to change at any time without notice. Data charges may apply. To learn more, go to www.toyota.com/audio-multimedia/. To learn more about Toyota's connected services data collection, use, sharing and retention practices, please visit www.toyota.com/support/privacy-notice/. Apple CarPlay and iPhone are registered trademarks of Apple Inc.
14. Wireless use of Android Auto requires a compatible Android 11.0+ phone and compatible active data plan. Check androidauto.com requirements for compatibility. Operability depends on network availability, a cellular connection and GPS signal. Services subject to change at any time without notice. Data charges may apply. To learn more, go to www.toyota.com/audio-multimedia/. To learn more about Toyota's connected services data collection, use, sharing and retention practices, please visit www.toyota.com/support/privacy-notice/. Android and Android Auto are trademarks of Google LLC.
15. Service will automatically stop at the end of your trial subscription period unless you decide to continue service. Trial is non-transferable. If you do not wish to enjoy your trial, you can cancel by calling the number below. All SiriusXM services require a subscription, each sold separately by SiriusXM after the trial period. Service subject to the SiriusXM Customer Agreement and Privacy Policy, visit siriusxm.com for complete terms and how to cancel which includes online methods or calling 1-866-635-2349. Some services and features are subject to device capabilities and location availability. Satellite service not available in AK & HI. Content varies by SiriusXM subscription plan. All fees, content and features are subject to change. SiriusXM and related logos are trademarks of Sirius XM Radio Inc. and its respective subsidiaries.
16. Toyota Connected Services vary by vehicle and are subject to change at any time without notice. Services depend on 4G network availability, a cellular connection and GPS signal. Without any one or more of these things, operability may be limited or precluded, including access to response center and emergency support. Further, if and when 4G network changes or is discontinued, or the underlying technology required to support service becomes obsolete, then the Connected Services will not work, and Toyota will need to discontinue impacted services. Services require account registration through the Toyota app and acceptance of the Connected Services Terms of Use at www.toyota.com/content/dam/toyota/privacyvts/pdf/connected-services-terms-use.pdf and Master Data Consent. Data charges may apply. For Toyota Connected Services' vehicle-generated data collection, use, sharing and retention practices and agreements, see www.toyota.com/support/privacy-notice/. All trials begin on original purchase or lease date of new vehicle, with the exception of Wi-Fi for which trial begins at time of activation. Paid subscription required after trial (if applicable).
17. Digital Key requires active Remote Connect subscription. Use only if aware of circumstances surrounding vehicle it is legal safe to do so (e.g., do not remotely start a gas engine vehicle in an enclosed space or if vehicle is occupied by a child). Remote Connect services vary by vehicle and are subject to change at any time without notice. Services depend on 4G network availability, a cellular connection and GPS signal. Without any one or more of these things, operability may be limited or precluded. Further, if and when 4G network changes or is discontinued, or the underlying technology required to support service becomes obsolete, then the services will not work and will need to be discontinued. Digital Key also requires Bluetooth connectivity. Not available on manual transmissions. Services require account registration through Toyota App and acceptance of Connected Services Terms of Use at www.toyota.com/content/dam/toyota/privacyvts/pdf/connected-services-terms-use.pdf and Master Data Consent. Data charges may apply. For Toyota Connected Services' vehicle-generated data collection, use, sharing, and retention practices and agreements, see www.toyota.com/support/privacy-notice/. Trial period begins on original purchase or lease date of new vehicle. Paid subscription required after trial (if applicable). Terms of Use apply.
18. Safety Connect services vary by vehicle and are subject to change at any time without notice. Services depend on 4G network availability, a cellular connection and GPS signal. Without any one or more of these things, operability may be limited or precluded, including access to response center and emergency support. Further, if and when 4G network changes or is discontinued, or the underlying technology required to support service becomes obsolete, then the services will not work, and will need to be discontinued. Stolen vehicle police report required to use Stolen Vehicle Locator. Automatic Collision Notification activates only in limited circumstances. Services require account registration through Toyota App and acceptance of Connected Services Terms of Use at www.toyota.com/content/dam/toyota/privacyvts/pdf/connected-services-terms-use.pdf and Master Data Consent. Data charges may apply. For Toyota Connected Services' vehicle-generated data collection, use, sharing, and retention practices and agreements, see www.toyota.com/support/privacy-notice/.
19. Service Connect depends on operative telematics device, 4G network availability and other factors beyond Toyota's control in order to operate, including 4G cellular network availability, a cellular connection and GPS signal. Without any one or more of these things, operability may be limited or precluded. Information provided is based on the last time data was collected from vehicle and is not real time data. Services may vary and are subject to change without notice. Services require account registration through Toyota App and acceptance of Connected Services Terms of Use at www.toyota.com/content/dam/toyota/privacyvts/pdf/connected-services-terms-use.pdf and Master Data Consent. Data charges may apply. For Toyota Connected Services' vehicle-generated data collection, use, sharing, and retention practices and agreements, see www.toyota.com/support/privacy-notice/.
20. Service not available everywhere or in every vehicle. Depends on 4G cellular network availability, a cellular connection and GPS signal. Without any one or more of these things, operability may be limited or precluded. Up to 5 devices can be supported using in-vehicle connectivity. Services subject to change at any time without notice. The Wi-Fi Connect trial begins at the time of enrollment and expires the earlier of 3GB data use or the 1-month trial period ends. Paid subscription required after trial. Integrated Streaming requires separate subscriptions to third-party provider services. Data charges may apply. Valid in the contiguous U.S. and Alaska. Go to

myvehicle.att.com/#/toyota/learn?language=en&country=US for terms and conditions. The Wi-Fi Connect trial begins at the time of enrollment and expires the earlier of 3GB data use or the 1-month trial period ends.

21. This floor liner was designed specifically for use in your model and model year vehicle and SHOULD NOT be used in any other vehicle. To avoid potential interference with pedal operation, each liner must be secured with its fasteners. Do not install a floor mat on top of an existing floor liner.
22. Crawl Control is designed for driving on difficult terrain at low speeds and assists driver by controlling acceleration and braking, allowing the driver to focus on steering. See *Owner's Manual* for additional limitations.
23. Downhill Assist Control is designed to help driver maintain vehicle control and speed on steep, downhill descents and Hill-Start Assist Control is designed to help minimize backward rolling on steep ascents. Neither system is a substitute for safe driving judgment and practices. Factors including speed, grade, surface conditions and driver input can affect the ability of the DAC and HAC to prevent a loss of control. See *Owner's Manual* for additional limitations.
24. HomeLink and HomeLink® house icon are registered trademarks of Gentex Corporation.
25. Rated for 12 volts/10 amps. See *Owner's Manual* for additional limitations and details.
26. Do not exceed 120V. See *Owner's Manual* for additional limitations and details.
27. Charging may not be compatible with all mobile phones, smart devices, tablets, e-readers, MP3/WMA players and like models.
28. SoftTex is a registered trademark of Toyota Motor Sales, U.S.A., Inc.
29. Airbag systems supplement the seatbelts and are designed to inflate only under certain conditions and in certain types of severe collisions. Always wear seatbelt, sit upright in middle and as far back in seat as possible to help decrease risk of injury. Do not put objects in front of an airbag See *Owner's Manual* for limitations.
30. The Panoramic View Monitor does not provide a comprehensive view of the area surrounding your vehicle. Look around to confirm clearance. See *Owner's Manual* for limitations.
31. The backup camera does not provide a comprehensive view. Always look over shoulder and use outside mirrors. See *Owner's Manual* for limitations.
32. When system is on, Electric Parking Brake is designed to engage Parking Brake under limited conditions and may not hold vehicle under all conditions. See *Owner's Manual* for additional limitations.
33. The Pre-Collision System (PCS) with Pedestrian Detection (PD) is designed to help reduce the crash speed and damage in certain frontal collisions involving a vehicle, a pedestrian, bicyclist or motorcyclist. PCS w/PD is not a substitute for safe and attentive driving. System effectiveness depends on many factors, such as speed, size and position of vehicle, pedestrian, bicyclist or motorcyclist and weather, light and road conditions. See *Owner's Manual* for limitations.
34. Smart Stop Technology will reduce power to help the brakes bring vehicle to a stop during certain contemporaneous brake and accelerator pedal applications. See *Owner's Manual* for limitations.
35. Dynamic Radar Cruise Control is not a substitute for safe and attentive driving. See *Owner's Manual* for instructions and limitations.
36. Requires cellular network availability, a cellular connection and GPS signal. May not work in all areas. Service may vary by vehicle and region. See Toyota dealer for details and exclusions.
37. Building and/or parking structures may limit system effectiveness. Stolen vehicle police report required to use Stolen Vehicle Locator. For additional assistance, contact the Toyota Brand Engagement Center at 1-800-331-4331.
38. Vehicle Stability Control is not a substitute for safe and attentive driving practices. Factors including speed, road conditions, weather and steering input can affect whether VSC will be effective. See *Owner's Manual* for limitations.
39. Lane Departure Alert with Steering Assist is designed to read visible lane markers under certain conditions. It provides a visual/audible alert and slight steering force when lane departure is detected. It is not a collision-avoidance system or substitute for safe and attentive driving. Effectiveness depends on many factors including road, weather and vehicle conditions. See *Owner's Manual* for limitations.
40. Automatic high beams operate at speeds above 21 mph. See *Owner's Manual* for instructions and limitations.
41. The Lane Tracing Assist (LTA) lane centering function is designed to read visible lane markers and detect other vehicles under certain conditions. It is only operational when DRCC is engaged. See *Owner's Manual* for limitations.
42. Road Sign Assist only recognizes certain road signs. See *Owner's Manual* for limitations.
43. Proactive Driving Assist (PDA) is designed to detect certain objects or curves in the road and provide gentle braking and/or steering support. PDA is not a substitute for safe and attentive driving. System effectiveness depends on many factors, such as speed, size and position of detected objects and weather, light and road conditions. See *Owner's Manual* for additional limitations and details.
44. Do not rely exclusively on Blind Spot Monitor. Look over shoulder and use turn signal. See *Owner's Manual* for limitations.
45. Do not rely exclusively on the Rear Cross-Traffic Alert. Visually confirm clearance during use. See *Owner's Manual* for limitations.
46. Trailer Merge Warning estimates a trailer's presence and length and may not function for all trailers and under all circumstances. The driver must use mirrors and physically check adjacent lanes before making lane changes.
47. Do not rely exclusively on Safe Exit Alert. Always look for approaching traffic before exiting the vehicle. See *Owner's Manual* for limitations.
48. Front and Rear Parking Assist with Automatic Braking (PA w/AB) may warn drivers of, and potentially brake for front and rear collisions with certain objects when traveling at low speeds. Drivers should visually confirm clearance during use. See *Owner's Manual* for instructions and limitations.
49. The Tire Pressure Monitor System alerts the driver when tire pressure is critically low. For optimal tire wear and performance, tire pressure should be checked regularly with a gauge; do not rely solely on the monitor system. See *Owner's Manual* for limitations and details.
50. Trailer Sway Control (TSC) is an electronic system designed to help the driver maintain vehicle control under certain conditions. It is not a substitute for safe driving practices. Factors including speed, road conditions, weather and driver steering input can all affect whether TSC will be effective in preventing a loss of control. See *Owner's Manual* for limitations.
51. The engine immobilizer is a state-of-the-art anti-theft system initiated when key is inserted into ignition switch or a Smart Key fob is in/near vehicle. Engine will only start if the code in transponder chip inside the key/fob matches code in vehicle's immobilizer. The

transponder chip is embedded in the key/fob and can be costly to replace. For lost key or FOB, see a Toyota dealer or go to www.aloa.org to find a qualified locksmith for high-security key service.

52. EPA-estimated 22 city/25 hwy/23 combined MPG rating for 2025 Land Cruiser 1958 4WD and Land Cruiser 4WD. Use for comparison purposes only. Your mileage will vary for many reasons, including your vehicle's condition and how/where you drive. See www.fueleconomy.gov.
53. Never tow beyond a vehicle's published towing capacities. Before towing, confirm your vehicle and trailer are compatible, hooked up and loaded properly and that you have any necessary additional equipment. The maximum you can tow depends on base curb weight plus the total weight of any cargo, occupants, and added vehicle equipment. Follow all instructions in your *Owner's Manual*. Installation of a tow hitch receiver or other accessories located near the rear bumper may require disabling or removing the kick sensor, and the sensor operation setting in your vehicle should be turned off. Follow all instructions in your *Owner's Manual*.
54. Hybrid-related components covered for 8 years from date of first use or 100,000 miles, whichever comes first. HV battery may have longer coverage under emissions warranty. See www.toyota.com/owners/warranty-owners-manuals/ for details.
55. For Toyota hybrid, plug-in hybrid, fuel cell and battery electric vehicles beginning model year 2020, hybrid (HV) battery covered for 10 years from date of first use or 150,000 miles, whichever comes first. Coverage subject to the terms and conditions of New Vehicle Limited Warranty. See www.toyota.com/owners/warranty-owners-manuals/ for details.
56. ToyotaCare covers normal factory scheduled maintenance for 2 years or 25,000 miles, whichever comes first, and 24/7 Roadside Assistance is for 2 years/unlimited mileage. Roadside Assistance does not include parts and fluids, except limited emergency gas delivery. Towing distance up to 25 miles. Restrictions apply. Available in the continental U.S. and Canada. See Toyota dealer for details and exclusions.
57. Cargo and load capacity limited by weight and distribution. Always properly secure cargo and cargo area.
58. Payload includes the weight of occupants, cargo and options and is limited by weight distribution.
59. Installation of a tow hitch receiver or other accessories located near the rear bumper or side-door kick sensors may require disabling or removing the kick sensor, and the sensor operation setting in your vehicle should be turned off. Water, weather, dirt, and other conditions also may cause the sensor to not operate properly or to operate unintentionally. See *Owner's Manual* for limitations.