




In addition to safety systems like Star Safety System™ and Toyota Safety Sense™¹, many Toyota models are also available with **Blind Spot Monitor (BSM)**² and **Rear Cross-Traffic Alert (RCTA)**³. These two systems are designed to work together to help assist with everyday driving, helping to inform the driver of vehicles that may not be visible in their line of sight. With this extra “pair of eyes” keeping a lookout, BSM w/RCTA may help prevent collisions with other vehicles – whether you’re cruising down the highway or slowly navigating around a parking structure.



Blind Spot Monitor (BSM)




Safely changing lanes on the road requires checking your side and rearview mirrors, and often looking over your shoulder, to spot vehicles traveling within close proximity. In some cases, however, **these checks may not be enough to spot a vehicle in the vehicle’s blind spot**, such as behind the vehicle’s C-pillar.

Blind Spot Monitor (BSM)² is designed to help in these situations by using radar sensors mounted in the rear bumper. When BSM detects a vehicle in the vehicle’s blind spot, it **illuminates a warning indicator** on the appropriate sideview mirror. If a turn signal is still activated despite this visual alert, the **mirror indicator will flash**.

When enabled, BSM² functionality is available when **surrounding vehicles are traveling at speeds above 10 mph**.

Rear Cross-Traffic Alert (RCTA)



Backing safely out of a parking spot requires reversing slowly to avoid a collision, especially since **vehicles parked adjacent to yours may prevent you from seeing traffic**.

When the vehicle is shifted into Reverse, the Rear Cross-Traffic Alert (RCTA)³ system is designed to **automatically activate** and begin using the BSM’s radar sensors to detect rear cross traffic approaching from either side of the vehicle. If a vehicle is spotted, the system will **notify the driver with an audio alert**, as well as with a **flashing indicator on the side mirrors**. The vehicle’s backup camera system or multimedia display will also **show an indicator to signal the direction of the approaching vehicle**.

RCTA³ functionality is available when **backing up at speeds up to 5 mph**, and when an **approaching vehicle is traveling at speeds between approximately 5 to 18 mph**.

How to Enable and Disable BSM w/RCTA



In most Toyota vehicles, the BSM² w/RCTA³ systems can be enabled and disabled through the vehicle's Multi-Information Display (MID).

To do this, just navigate to the MID's Settings screen, then find the BSM setting, then simply toggle it on or off. Please note that on certain vehicles, BSM² and RCTA³ cannot be enabled or disabled individually.

Some vehicles may use a dedicated physical button on the dash to enable and disable the BSM² system. Please check your vehicle *Owner's Manual* for more information.

BSM w/RCTA: 2018-2019 Applicability

Avalon		
2018	XLE Premium / XLE Premium Hybrid	Standard
	Limited / Limited Hybrid	Standard
	Touring	Standard
2019	XLE / XLE Hybrid	Standard
	XSE / XSE Hybrid	Standard
	Limited / Limited Hybrid	Standard
	Touring	Standard
C-HR		
2018	XLE Premium	Standard
2019	XLE	Standard
	Limited	Standard
Camry		
2018-2019	LE / LE Hybrid	Available
	SE / SE Hybrid	Available
	XSE	Standard
	XLE / XLE Hybrid	Standard
Corolla Hatchback		
2019	SE (BSM only)	Available
	XSE (BSM only)	Standard
Highlander		
2018-2019	LE Plus	Standard
	SE	Standard
	XLE / XLE Hybrid	Standard
	Limited / Limited Hybrid	Standard
Land Cruiser		
2018-2019	Land Cruiser	Standard
Mirai		
2018	Mirai	Standard
2018 Prius		
2018	Four	Standard
	Four Touring	Standard

2018 Prius Prime		
2018	Advanced	Standard
RAV4		
2018	XLE / XLE Hybrid	Available
	Adventure	Available
	SE	Available
	SE Hybrid	Standard
	Limited / Limited Hybrid	Standard
	Platinum	Standard
Sequoia		
2018-2019	SR5	Standard
	Limited	Standard
	Platinum	Standard
	TRD Sport	Standard
Sienna		
2019	LE	Available
2018-2019	SE	Available
	XLE	Standard
	Limited	Standard
Tacoma		
2018-2019	Limited	Standard
	TRD Sport	Available
	TRD Off-Road	Available
	TRD Pro	Standard
Tundra		
2018-2019	SR5	Available
	Limited	Available
	Platinum	Standard
	1794 Edition	Standard



TOYOTA

Blind Spot Monitor and Rear Cross-Traffic Alert System Overview and Applicability

OCT
2018

DISCLOSURES

1. Drivers are responsible for their own safe driving. Always pay attention to your surroundings and drive safely. System effectiveness is dependent on many factors including road, weather and vehicle conditions. See Owner's Manual for additional limitations and details. **2.** Do not rely exclusively on the blind spot monitor. Always look over your shoulder and use your turn signal. There are limitations to the function, detection and range of the monitor. See Owner's Manual for additional limitations and details. **3.** Do not rely exclusively on the Rear Cross-Traffic Alert system. Always look over your shoulder and use your mirrors to confirm rear clearance. There are limitations to the function, detection and range of the system. See Owner's Manual for additional limitations and details.